

SWING-ARM TYRE CHANGER



SWING-ARM

The mounting arm swings to the side so that the machine can be installed in a space-saving way directly near a wall.



ON-FLOOR BEAD BREAKER (PEDAL-OPERATED)

Traditional side-shovel bead breaker with ergonomic pedalcontrol positioned away from the shovel; the fastest solution for standard, soft sidewall, and highaspect tyres



TOP-SIDE BEAD SEATER

This ergonomic hand-held nozzle injects a high-speed blast of air into the tyre to raise the bead and seal the tyre to the rim.



T1300B



TECHNICAL SPECIFICATIONS

Max Rim Diameter	22" 56cm
Max Tyre Width	13" 33cm
Max Wheel Diameter	39" 100cm
Power Supply	400V 3ph 50Hz 5,5A
Air Pressure Required	116-174 PSI 8-12 bar
Dimensions HxWxD	50"x68"x45" 125x173x115cm

STANDARD ACCESSORIES

- 1 kg Lube Bucket Holder
- Tyre Lever Wave Plus
- · Plastic Protectors for Mounting Head

OPTIONAL ACCESSORIES

- Lube Brush
- Plastic Rim Protector
- Plastic Tyre Protector
- · Smart Bead Spacer
- Bead Clamp
- · Plastic Protector for Bead Breaker Blade
- · Bead Breaker Blade for Off-**Road Wheels**

iohnbean.com

· Roller Board



FIND A DISTRIBUTOR







